

# SNO-GEM

## 1- Installation

- a) Spread bead of sealant evenly all around the Sno-Gem base.
- b) Place Sno-Gem in position on metal surface, applying light, even pressure perpendicular to roof surface. Insure solid backing underneath the Sno-Gem.
- c) Use screws with neoprene gaskets through pilot holes in Sno-Gem and tighten to cause approximately 50% compression in neoprene gasket.
- d) Four screws to be used per Sno-Gem.

## 2- Materials

Clear, Polycarbonate polymer

## 3- Manufacturer

SNO-GEM, INC.  
4505, Prime Parkway  
Mc. Henry, IL (60050)  
Toll Free: 888-SNO-GEMS (766-4367)  
Website: [www.snogem.com](http://www.snogem.com)

